
WARNING - MUST READ

DO NOT USE ANY CHARGING ADAPTORS WITH THE VACUUM CLEANER OTHER THAN THE ONE SUPPLIED.

DO NOT USE THE VACUUM CLEANER WITHOUT THE HEPA
FILTER OR FILTER CONE IN POSITION; THE HEPA FILTER AND
FILTER CONE MUST BE CORRECTLY FITTED BEFORE USE


FAILURE TO ADHERE TO THE ABOVE COULD CAUSE DAMAGE TO THE VACUUM CLEANER.

1




PRESS THE DUST CONTAINER RELEASE BUTTON AND PULL THE DUST CONTAINER AWAY FROM THE VACUUM CLEANER.

2.



REMOVE THE FILTER CONE AND HEPA FILTER FROM THE DUST CONTAINER.


3.





5.

LOCKING TABS



CAREFULLY WASH THE HEPA FILTER IN WARM WATER AND ALLOW IT TO DRY THOROUGHLY. ONCE COMPLETELY DRY, REFIT THE HEPA FILTER INTO THE FILTER CONE AND RETURN TO THE DUST CONTAINER

REFIT THE DUST CONTAINER INTO THE VACUUM CLEANER BY ALIGNING ITS LOCKING TABS WITH THE SLOTS ON THE MAIN UNIT, THEN PUSH THE DUST CONTAINER SECURELY INTO PLACE.

IMPORTANT: DO NOT ALLOW THE DUST CONTAINER TO OVERFILL; CLEAN IT REGULARLY. FAILURE TO CLEAN THE FILTERS MAY RESULT IN POOR PERFORMANCE AND LOSS OF SUCTION POWER.

2 IN 1 CREVICE/BRUSH TOOL: PULL THE BRUSH HEAD AWAY FROM THE TOOL TO USE THE CREVICE FUNCTION; REATTACH THE BRUSH HEAD TO USE THE BRUSH FUNCTION.